


S O L A R A[®]

ELECTRIC KETTLE

INSTRUCTION MANUAL

Model: SOL-KET-100- 1500W / 220-240V / 50-60 Hz



**1.8 Liter
CAPACITY**

Table of Contents

Table of Contents	2
Welcome to the SOLARA Family!	3
Before You Begin	4
General Safety Regulations	4, 5
KNOW YOUR SOLARA ELECTRIC KETTLE	5
USING YOUR SOLARA ELECTRIC KETTLE	6
Care & Maintenance	6

Please read and save all instructions to ensure safe and effective use of this appliance.

CARE & MAINTENANCE

Warning: Always unplug the kettle from the socket and allow it to cool completely before cleaning or descaling it.

- Clean the exterior surface of the kettle with a damp cloth and then polish it with a soft dry cloth. Do not use steel wool pads or harsh/abrasive cleaners, which may damage the body.
- Do not immerse the power base or power cord in water or liquid of any kind.
- This kettle features a concealed heating element which means it never comes into contact with the water inside the kettle. This hygienic design not only makes cleaning the inside of the kettle much easier, it also keeps cleaning to a minimum.
- **Descaling your kettle :**
- Boil water with one cup baking soda.
- Cool down for 10 minutes.
- Use brush to clean the inner part.
- Remove the stains and pour out the boiled water . Clean with cool water.
- Wipe the outer with cloth.
- Dry with a soft cloth.

USING YOUR SOLARA ELECTRIC KETTLE

- Set the desired length of the power cord.
- Fill the kettle with the required amount of water. The water level must reach at least the minimum mark and must not exceed the maximum mark . You may fill the kettle after lifting the lid. The lid can only be opened once the lid lock, located in the middle of the lid, is released. After filling the kettle with water, close the lid and push it down so that it is secured in the closed position.



Warning! Never fill the kettle when it is located on the base. If the electric kettle is overfilled, then boiling water could splash out.

- Place the kettle on the base. Insert the power plug into an electrical power socket. Check that the lid of the kettle is closed.
- The indicator light will turn ON. Once the water gets heated up, the indicator light will turn OFF.



Attention: Do not turn on the kettle when it is empty. If you accidentally turn on the electric kettle without water, the thermostat will, after reaching a certain temperature, turn the kettle off. In such a case, it is normal to observe a burnt smell. Please wait till the kettle has cooled down, before turning it on again (after filling it with water) and The kettle can be used again after several minutes, as soon as its stainless steel bottom has cooled down.

- When the water starts to boil, the kettle will turn off automatically and the kettle light inside will turn off. Before taking the kettle off the base, check that it has turned itself off automatically. If it has not automatically turned itself off, turn off the kettle manually by setting the switch to position 0 (Off).



Note: The operation of the kettle can be interrupted at any time by setting the switch to position 0 (Off).

- Pour the boiled water into a prepared container, cup or mug. Make sure that it remains in a vertical position when it is carried, particularly if it is filled all the way up to the maximum mark. If you wish to open the lid to refill the kettle, first empty all the contents of the kettle so that you are not scalded by the escaping steam.
- After you finish using the kettle, disconnect the power socket. Empty the kettle and allow it to cool down.

WELCOME TO THE SOLARA FAMILY!

At SOLARA, we are all about making healthy choices. And eating healthy should always be considered in this journey. Truly we are what we eat. So, here we are with an awesome appliance to aid you in this journey. Also, we are constantly working to create EASY, TASTY & HEALTHY recipes for you!

We can't wait to see how you make the SOLARA Electric Kettle part of your everyday, please feel free to share it with us on social media: @solaraindia.

BEFORE YOU BEGIN

- Remove all packing materials and make sure that the product has been received in good condition. Taking care to keep the electrical components on the exterior of the kettle dry, wipe the interior of the kettle with a damp cloth. If your hand will not fit inside the kettle, swish warm, soapy water around in the interior of the kettle with the lid closed.
- Rinse out the inside of the kettle thoroughly with water.
- With a damp cloth, gently wipe off the exterior of the kettle. Do not wipe electrical components as this may cause damage to the unit.
- Dry all parts completely.

GENERAL SAFETY REGULATIONS

When using electrical appliances, basic safety precautions should always be followed including the followings.

READ ALL INSTRUCTIONS BEFORE USING & SAVE THESE INSTRUCTIONS :

- Do not use or store the unit in damp and moist areas where it may come in contact with water.
- Keep out of the reach of children.
- Do not immerse the unit, cord, plug or power base in water or other liquid.
- Use the handle to carry or move the unit, as the surface may be hot after use and to avoid scalding from hot liquid.
- Use caution to not touch the power base or bottom of the kettle after use to avoid scalding or burns.
- Close supervision is necessary when this appliance is to be used by or near children.
- Unit must be operated on a flat surface away from the edge of counter to prevent accidental tipping.
- Use the appliance only on the voltage specified on the identification plate.
- Do not use the kettle if it has been damaged or modified or appears to have malfunctioned in any way.
- Do not operate the kettle with a damaged or incorrect cord or plug.
- This kettle is intended for heating water only. Use of any other liquids or food may damage the interior and void warranty. Do not allow the cord to hang over the edge of the table or counter, or contact any hot surfaces.
- This kettle is designed for Household use only! Do not use outdoors.
- When not in use and before cleaning, disconnect the kettle from the outlet. Allow the kettle to cool completely before attempting to clean.
- Do not remove the lid during the heating cycle. Scalding may occur.
- Do not operate the kettle without water. If the unit overheats, please allow the unit to cool for at least 15 minutes.
- Do not fill above the MAX line; this may cause water to overflow, which may cause scalding.
- Steam may damage walls or cabinets, during use turn the spout away from walls toward an open space; use heat resistive pads under the kettle to prevent damage to wood finishes.
- Do not place or use the unit on or near a hot gas or electric burner or in a heated oven.
- Never operate the appliance when the lid is open or removed.
- Do not use or store the unit in damp and moist areas where it may come in contact with water.
- Keep out of the reach of children.
- Do not immerse the unit, cord, plug or power base in water or other liquid.
- Use the handle to carry or move the unit, as the surface may be hot after use and to avoid scalding from hot liquid.

- Use caution to not touch the power base or bottom of the kettle after use to avoid scalding or burns.
- Close supervision is necessary when this appliance is to be used by or near children.
- Unit must be operated on a flat surface away from the edge of counter to prevent accidental tipping.
- Use the appliance only on the voltage specified on the identification plate.
- Do not use the kettle if it has been damaged or modified or appears to have malfunctioned in any way.
- Do not operate the kettle with a damaged or incorrect cord or plug.
- This kettle is intended for heating water only. Use of any other liquids or food may damage the interior and void warranty. Do not allow the cord to hang over the edge of the table or counter, or contact any hot surfaces.
- This kettle is designed for Household use only! Do not use outdoors.
- When not in use and before cleaning, disconnect the kettle from the outlet. Allow the kettle to cool completely before attempting to clean.
- Do not remove the lid during the heating cycle. Scalding may occur.
- Do not operate the kettle without water. If the unit overheats, please allow the unit to cool for at least 15 minutes.
- Do not fill above the MAX line; this may cause water to overflow, which may cause scalding.
- Steam may damage walls or cabinets, during use turn the spout away from walls toward an open space; use heat resistive pads under the kettle to prevent damage to wood finishes.
- Do not place or use the unit on or near a hot gas or electric burner or in a heated oven.
- Never operate the appliance when the lid is open or removed.

KNOW YOUR SOLARA ELECTRIC KETTLE

